



# Taylor Bin 80L

1



2




- Remove baseplate cover attached with 6x M5 countersunk socket screws
- Position bin
- Mark 4x hole centres through mounting holes

- Use hammer drill with 12mm masonry bit to drill marked holes minimum depth 155mm
- Clear holes with wire brush or compressed air
- Fill holes with chemset epoxy
- Insert M12 x 180mm threaded anchor bolt into each hole. Ensure between 25mm and 30mm of each anchor bolt protrudes above mounting surface
- Allow chemset epoxy to set according to manufacturer's instructions


# Taylor Bin 80L

3



- Place bin onto anchor bolts
- Thread 1x M12 washer and 1x M12 nylock nut onto each anchor bolt
- Use socket wrench to securely tighten M12 nylock nuts

4




- Replace baseplate cover

Note:


- All tools and installation fixings to be supplied by contractor
- Footing design to be determined by site engineer based on local conditions
- Mos recommends minimum pad footing 500mm x 500mm x 300mm

# Taylor Bin 80L

1



2





- Remove baseplate cover attached with 6x M5 countersunk socket screws
- Position bin
- Mark 4x hole centres through mounting holes

- Use hammer drill with 12mm masonry bit to drill marked holes minimum depth 155mm
- Clear holes with wire brush or compressed air
- Fill holes with chemset epoxy
- Insert M12 x 180mm threaded anchor bolt into each hole. Ensure between 25mm and 30mm of each anchor bolt protrudes above mounting surface
- Allow chemset epoxy to set according to manufacturer's instructions



# Taylor Bin 80L

3



- Place bin onto anchor bolts
- Thread 1x M12 washer and 1x M12 nylock nut onto each anchor bolt
- Use socket wrench to securely tighten M12 nylock nuts

4



- Backfill or pave to FGL
- Replace baseplate cover

Note:

- All tools and installation fixings to be supplied by contractor
- Footing to be set with mounting surface at 150mm below FGL
- Footing design to be determined by site engineer based on local conditions
- Mos recommends minimum pad footing 500mm x 500mm x 300mm